



Figure 3-I. CORSIM data structure.

Tables 3-1 and 3-2 list the record types that can be used by each model. The run control data shown in table 3-1 is independent of the model that is being executed and is required for **all** models. Only one set of run control data records is permitted, even if more than one model will be executed.

Table 3-I. Run control data required to set up CORSIM simulation runs.

RECORD TYPE	DESCRIPTION	NETSIM	FRESIM
00	Run Title	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
01	Run Identification	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
02	Run Control	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
03	Time Period Specification	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
04	Time Intervals and Time Steps per Time Period	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
05	Reports and Graphics	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>